

Update Information

Model Number

Europe

LCD models

TX-49EXW58	TX-55EXW584		
TX-40EX600E	TX-40EX603E	TX-40EX610E	TX-40EX613E
TX-40EX620E	TX-40EX633E	TX-40EXW604	TX-40EXW604S
TX-43EXW604	TX-49EX600E	TX-49EX603E	TX-49EX610E
TX-49EX613E	TX-49EX620E	TX-49EX633E	TX-49EXW604
TX-49EXW604S	TX-55EX600E	TX-55EX603E	TX-55EX610E
TX-55EX613E	TX-55EX620E	TX-55EX633E	TX-55EXW604
TX-55EXW604S	TX-65EX600E	TX-65EX603E	TX-65EX610E
TX-65EX613E	TX-65EXW604	TX-40EXF687	TX-40EXN688
TX-40EXT686	TX-40EXX689	TX-49EXF687	TX-49EXN688
TX-49EXT686	TX-49EXX689	TX-55EXF687	TX-55EXN688
TX-55EXT686	TX-55EXX689		
TX-40EX700E	TX-40EX703E	TX-40EXM715	TX-50EX700E
TX-50EX703E	TX-50EXM715	TX-58EX700E	TX-58EX703E
TX-58EXM715	TX-65EX700E	TX-65EX703E	TX-65EXM715
TX-40EX730E	TX-40EXW734	TX-40EXW735	TX-50EX730E
TX-50EXW734	TX-50EXW735	TX-58EX730E	TX-58EXW734
TX-65EX730E	TX-65EXW734	TX-43EXW754	TX-50EX780E
TX-50EXF787	TX-50EXN788	TX-50EXT786	TX-50EXW784
TX-50EXX789	TX-58EX780E	TX-58EXF787	TX-58EXN788
TX-58EXT786	TX-58EXW784	TX-58EXX789	TX-65EX780E
TX-65EXF787	TX-65EXN788	TX-65EXT786	TX-65EXW784
TX-65EXX789	TX-75EX780E	TX-75EXW784	

OLED models

TX-55EZ950E	TX-55EZX954	TX-55EZW954	TX-65EZ950E
TX-65EZX954	TX-65EZW954	TX-65EZ1000E	TX-65EZX1004
TX-65EZW1004	TX-77EZ1000E	TX-77EZX1004	TX-77EZW1004

UK and Ireland

LCD models

TX-49EX580B	TX-55EX580B		
TX-40EX600B	TX-49EX600B	TX-55EX600B	TX-65EX600B
TX-40EX700B	TX-50EX700B	TX-58EX700B	TX-65EX700B
TX-50EX750B	TX-58EX750B	TX-65EX750B	TX-75EX750B

OLED models

TX-55EZ952B TX-65EZ952B TX-65EZ1002B TX-77EZ1002B

CIS**LCD models**

TX-40EXR600 TX-55EXR600 TX-49EXR600
 TX-50EXR700 TX-58EXR700 TX-75EXR780

OLED models

TX-55EZR950 TX-65EZR1000 TX-77EZR1000

Update Version Version 3.239
 Update File Name / Size P173_3239_G604M29.zip / 196,794,973 bytes
 Update Date Aug. 18, 2021

Improvements

Date/Version	Description
Aug. 18, 2021 Ver. 3.239	1. Improve system stability. 2. Improve network applications.
Jul. 30, 2019 Ver. 3.231	1. Improve network applications.
Oct. 23, 2018 Ver. 3.211	1. Improve network applications.
Jul. 17, 2018 Ver. 3.200	1. Improve system stability.
Aug. 22, 2017 Ver. 3.142	1. Improve network applications.
Jun. 27, 2017 Ver. 3.131	1. Improve network applications.
May 23, 2017 Ver. 3.122	1. Improve network applications.

Firmware Update Procedures

Perform steps 1 through 4 listed below.

Step 1: Check the current version of firmware used by your TV.

Step 2: Download an updated version of the firmware and double click the downloaded file to decompress it.


- Step 3: Copy the firmware file onto a USB flash memory.
- Step 4: Install the firmware update.

Step 1. Check the current version of firmware used by your TV.


Panasonic recommends that you update the firmware in your TV if the firmware version indicated is older than the version being offered. Please check the current version of firmware in following procedure.
(Your TV screen might have difference from the following examples, but the steps are the same.)

Steps


1. Turn the power ON
2. Press [Menu] button to display Main Menu
3. Select "Help" in Main menu



4. Select "System information" in "Help Menu"



5. Confirm "software Version"



If the firmware version indicated is older than the version being offered, then please update the firmware.
(Please update firmware, if [****] is smaller than [3239].)

Use of software downloaded from this site requires agreement with the License Agreement. Please review the contents of the License Agreement beforehand.

Please go to Step2 when agreeing to the agreement.

You can download source code for the programs licensed under the GNU LESSER General Public License from the following button.

[Source code download](#)

Step 2 : Download an updated version of the firmware and decompress it.

1. Make a temporary folder on your PC for downloading the file,e.g. C:\Temp.
2. Click the button to download and save the firmware in the folder you created in the above step.

[download](#)

3. Double click the downloaded file PXXX_XXX.zip

Depending on your browser settings the file may be downloaded automatically into your "DOWNLOAD" folder. If it's not automatically decompressed please use an archiver software to do that.